

		レベルセンサー														数値表示センサー					
Nikon	SP	LS-1	LS-3	LS-5	LS-6	LS-7	LS-8	LS-12	LS-15	LS-16						DS-30	DS-30V	DS-30V II			
			1077	1175/ 1177	1275	HR-500	HR-550	2077	3075	175/ HR-200	HR-300	HR-320	HR-350	HR-150U	CR600				HL-450	HL-700	
			70,000	60,000	50,000	50,000	50,000	79,000	60,000	50,000	30,000	40,000	30,000	30,000	120,000	83,000	83,000	75,000	45,000	55,000	
AL-1	EL-1	⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-2	EL-2	⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-2A		⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-3		⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-20	L200	⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-30	L350	⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-22	L220	⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-50	L500	⊙	⊙	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	⊙	⊙	⊙	⊙	⊙	
AL-12	L125	×	×	×	×	×	×	⊙	⊙	△	×	×	×	×	×	×	×	×	×	×	
AL-15	L130	×	×	×	×	×	×	⊙	⊙	△	×	×	×	×	×	×	×	×	×	×	
NL-100E	1004	×	×	×	×	×	×	△	△	⊙	×	×	×	×	×	×	×	×	×	×	
NL-220C	L500C・LL500	×	×	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	⊙	×	⊙	⊙	⊙	⊙	
NL-300E	L600	×	×	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	⊙	×	⊙	⊙	⊙	⊙	
NL-500E	1480	×	×	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	⊙	
NL-600	LL-600	×	×	⊙	⊙	⊙	⊙	×	×	×	⊙	⊙	⊙	×	⊙	×	⊙	⊙	⊙	⊙	
	LL-200	×	×	×	×	×	×	⊙	⊙	⊙	×	×	×	×	×	×	×	×	×	×	
	LL-300	×	×	×	×	×	×	⊙	×	×	⊙	⊙	⊙	×	⊙	×	×	×	⊙	⊙	
	LL-400	×	×	×	×	×	×	⊙	×	×	×	⊙	⊙	×	⊙	×	×	×	⊙	⊙	
	LL100	×	×	×	×	×	×	×	×	×	×	⊙	⊙	×	×	×	×	×	⊙	⊙	
	HV301G	×	×	×	×	×	×	×	×	×	×	×	×	⊙	×	×	×	×	×	×	
	HV401	×	×	×	×	×	×	×	×	×	×	⊙	⊙	×	⊙	×	×	×	⊙	⊙	
	HV101	×	×	×	×	×	×	×	×	×	×	⊙	⊙	×	×	×	×	×	⊙	⊙	
スタッフアダプタ		↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	↓	
Nikonモデル		LS用	LS3用	LS5用	LS6用	LS7用	LS8用	LS12/15用	LS16用							DSスタッフアダプタ					
SPモデル			1071	1171	1271	C50	C57	2071	1271-1	C55	C59	C59	C61	C50・C51マグネット					HL-450用	HL700用	
本体価格		8,000	7,000	7,000	6,000	7,700	7,700	6,000	6,000	5,000	5,000	5,000	5,000	7,700			3,000		7,000	10,000	

△印はセンサーが反応はするが、保証していないか、仕様に満たない。